



Video Flex[®]

7300

The Video Flex 7300 TEACHER'S CHOICE includes all the features of the 7200, plus the industry's first innovations. The Manual Contrast controls adjust to any lighting condition, the Positive/Negative switch reverses the video image to highlight details, and the Fluorescent Control eliminates the pulse caused by antiquated fluorescent lighting.



Additional Features and Benefits



- ✂ **Triangular Base**
 - ✂ **500 Lines of Resolution**
 - ✂ **Poly-Carbonate Build**
 - ✂ **C-mount Lens**
 - ✂ **Quick Focus[™]**
 - ✂ **Ball and Socket Head**
 - ✂ **Microphone**
 - ✂ **Discovery Scope Kit**
 - ✂ **Kensington Slot**
 - ✂ **1.5 Lux**
- Slip and Tip proof
 - For crisp clear pictures
 - Allows for rugged conditions and environments
 - Interchangeable lens system accommodates all C-mount lenses.
 - 1/4 turn moves from 6mm to infinity
 - For greater range of motion and easier positioning
 - For recording or amplifying
 - To bring nature into the classroom
 - Provides anti-theft control
 - Operates in low light conditions

7300 SPECIFICATIONS

Weight	5.95 lbs / 2.70 Kg
Base Material	Polycarbonate
Base Dimension	7"x7"x7" / 18x18x18 cm
Height	30" / 76.2 cm
Head Type	Ball and Socket
Lens	8 mm
Focus	1/4 turn Quick Focus [™]
Focal distance	1/4" / 6mm to Infinity
Light Sensitivity	1.5 Lux
Resolution	500 Lines
Magnification	50:1 and Greater

Exposure	Adjustable Contrast
Output Signal	Composite and S-VHS
Eyepiece Adapters	28mm & Built-in 34.5 mm
Advanced Features	Contrast Control Buttons
	Positive/Negative Switch
	Fluorescent Control Switch
Options Included	Discovery Scope Kit & Case
Cable	12' A/V
Warranty	5 Years



(816) 353-4787 ✂ Fax (816) 358-5072

email: info@ken-a-vision.com